


# Fosmon TSA Approved 3 Digit Combination Cable Luggage Lock

Thank you for purchasing this Fosmon product. This guide will help you to familiarize yourself with all the features and functions of the product.

## **Disclaimer Statement**

We are not liable for any damage or destruction to personal properties that are contained inside or outside of the Fosmon product. We are not liable to you or anyone else for any loss, injury, or damages relating to this product.

## TSA Lock



# **How to Use**

- 1. Dial your numbers to the convex line, pull the shackle to open.
- 2. Insert the shackle and scramble the numbers to lock. Repeat above to reset.

## Follow Us On Social Media



www.fosmon.com support@fosmon.com © 2018 Fosmon Inc. All rights reserved.

All trade names are registered trademarks of respective manufacturers listed.

## **Recycling the Product**

To dispose this product properly, please follow the recycling process regulated in your area.

WARNING: This product can expose you to DINP which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

## **FCC Information**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



### DO NOT RETURN THE PRODUCT

There are good days and there are bad days. It is our BAD if the product is not working, or if you are not happy with it. PLEASE GIVE US A CHANCE and WE WILL MAKE IT RIGHT.

1-833-3-Fosmon (833-336-7666) (612) 435-7508 support@fosmon.com

**How to Set** 

The original combination is 0-0-0.

- 1. Turn the dial [B] to the original combination.
- 2. Press button [A] to release the shackle.

Limited Lifetime Warranty

- 3. Press down and hold the reset button [C] with a pen or other tool while turning the dial [B] to set your new combination.
- 4. Release the reset button [C] only after you have completed setting the new combination.

This Fosmon product includes a limited lifetime warranty.

Please visit our Fosmon website for more details.