

C-10808 UM
Size: 12x8 cm
Foldable



**PS5 Wall Mount with Dual Charging Dock
USB-C and USB-A ports, and RGB Lights
White**



PLEASE DO NOT RETURN THIS PRODUCT

There are good days and bad days. If there is a problem with your product or you are unhappy with it,

**PLEASE GIVE US A CHANCE TO
MAKE IT RIGHT.**

Email: support@fosmon.com
US Toll Free: 1-833-3-FOSMON
(833-336-7666)
Local/International: (612) 435-7508

© 2023 Fosmon Inc. All rights reserved.

v10.25.2023

Thank you for purchasing this Fosmon product. For optimum performance and safety, please read this user manual carefully before operating and keep it for future reference.

Fosmon's wall mount with controller charging dock for the PS5 gives you the ability to mount your PS5 onto the wall, granting you a cleaner PS5 setup. This wall mount is built to support both of the digital and disc versions of the PS5. Alongside the wall mount, there is also a controller charging station that can be connected to the wall mount, allowing you to charge two controllers simultaneously. Not only that, but this controller charging station also has built-in RGB LEDs with multiple configurations, enabling you to select the RGB LEDs that looks best for your setup.


Package Includes

- 1x Wall Mount
- 1x Charging Dock
- 6x Wall Screws
- 6x Anchors
- 1x USB-C to USB-C Cable (3.28ft)
- 1x User Manual

Specifications

Working Voltage	DC 5V/3A
Charging Output	DC 5V/2.5A
Product Material	ABS
Charges	PS5 DualSense Controller & PS5 Edge Controller
PS5 Compatibility	Digital Version & Disc Version


Product Diagram



Powering on the Charging Dock/RGB LEDs

Connect the provided USB-C to USB-C cable to your PS5's USB-C port and the other end into the charging dock's USB-C port to give it power. The PS5 needs to be powered on for the charging dock/RGB LEDs to work.

Connecting the Charging Dock to Wall Mount



1. Line up the hook/tab holes on the controller charger with the wall mount's protruding hooks/tabs.
2. After lining them up properly, insert the wall mount's protruding tabs into the controller charger's tab holes. Make sure to press with applicable force to ensure that the two pieces connect firmly.

Mounting Instructions

1. Find a dry wall or applicable surface that you would like to install the wall mount to.
2. Line up the wall mount to your surface so you know where to exactly drill your 5 holes. Refer to the product diagram to see where the mounting holes are located.
3. After lining up and marking the locations where you will be drilling, drill the 5 holes for where the mounting screws/anchors will go. If you are unsure of drilling, please contact a professional or have a person that knows how to drill holes properly to do the drilling.
4. After drilling your 5 holes, install the anchors into the drilled holes.
5. Line up your wall mount to those 5 holes, and then screw or drill in your wall screws into the said holes/anchors. Make sure to drill it thoroughly and make sure the wall mount is firmly secured to the wall.
6. Put your P55 system on top of the wall mount vertically. It should sit perfectly on the wall mount.

Optional: Use your mounting screw that comes with your PS5's stand and screw your PS5 to the wall mount from the bottom of the wall mount to ensure more stability.

Controller Charging Instructions

1. Put your PSS DualSense controller/PSS Edge controller on the charging ports to charge your controllers. The controller's charge from the bottom of your controller, so line up the bottom of your controller to the pins on the controller chargers.
2. The charging indicator will turn orange when it is charging. When the controller is fully charged, the charging indicator will turn blue.

RGB LED Controller

1. Hold the RGB button down for 3 seconds to turn the RGB LEDs on or off.
2. Short press the RGB button to cycle through the various RGB color configurations. You can leave it on a solid color, or use the breathable RGB configurations. Use your favorite RGB LED lighting for your setup.

Troubleshooting / Common Issues

1. Charging dock not charging or RGB LEDs not working.
 - A. Ensure that the USB-C cable is properly plugged into your P55 and the charging dock.
2. Can't turn off the RGB LEDs.
 - A. Long press the RGB button for 3 seconds to turn off your RGB LEDs. If you want to turn on your RGB LEDs, long press the RGB button for 3 seconds to turn on the RGB LEDs.
3. Charging indicator stays blue and never turns orange.
 - A. If the charging indicator does not turn orange, most likely your controller is already fully charged. If the charging indicator is blue, it means your controller is fully charged. When it is orange, that means the controller is still charging.

Safety Precautions

- Do not attempt to open the product to prevent electrical shocks.
- Make sure you drill your wall screws firmly to the mount to ensure stability.
- Do not expose the PS5 or charging dock to water, moisture, or high-humidity environments to avoid the risk of damage.

FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Limited Lifetime Warranty

Visit fosmon.com/warranty for Product Registration, warranty and limited liability details.

Recycling the Product

To dispose this product properly, please follow the recycling process regulated in your area.